



IOLAN SCR226/SCRC226 SCR242/SCRC242 SCR258/SCRC258 Quick Setup Guide

This guide covers basic installation and configuration and is intended for first-time setup or product evaluation.

Additional information can be found at

<http://www.perle.com/downloads/>

<http://www.perle.com/downloads>

- IOLAN SCR User's Guide
- IOLAN SCR Command Line Reference Guide
- IOLAN SCR Hardware Installation Guide

What's in the box?


- ✓ IOLAN SCR unit
- ✓ 2 power cords (depending on the order)
- ✓ 2 antennas (for cellular SCRC226, SCRC242, and SCRC258 models)

What do you need to supply


- ✓ Serial cables to connect serial devices to your SCR
- ✓ Ethernet CAT5/5e/CAT6 10/100/1000BASE-T cables to connect Ethernet devices to your SCR
- ✓ SFP modules (if needed)
- ✓ Fiber cables (if needed)
- ✓ SIM cards for cellular models SCRC226, SCRC242, and SCRC258 models

Hardware Views

SCR Console/USB Port View with Cellular



SCR Serial Port View



LEDs

	LED Colour/Action	Description
SYS	Off Red Amber-solid Amber-flashing Green-solid Green-flashing	No power Power has been applied Kernel loading System is booting Normal operation No configuration or in Safe Mode
PWR1	Off Green-solid-On Amber-solid	No power was supplied to PWR 1 Power 1 is On Dual power enabled, power supply 1 is not operational
PWR2	Off Green-solid-On Amber-solid	No power was supplied to PWR 2 Power 2 is On Dual power enabled, power supply 2 is not operational

Powering up the SCR for the First Time

Connect 1 or 2 power plugs to the power sockets. Turn the power switch/s to the ON (UP) position. The SYS LED will slowly blink amber until the unit is fully powered. When a flashing green System LED appears, it means the SCR has no configuration and is ready to start the Fast Setup sequence. If dual power is used, then PWR LEDs 1 and 2 will be lit.

Setting up the SCR for the First Time

The IOLAN can be initially set up using DHCP (ZTP Mode) or via the Fast setup method using an Ethernet or console connection.

Option 1–DHCP Mode

Your IOLAN is in factory default mode with the DHCP client enabled on all the up-link (SFP) ports. Connect one of

your up-link ports to your network to allow it access to your DHCP server. The DHCP server can now provide IP information to the IOLAN and, optionally, a full configuration file and/or firmware image. If the IOLAN cannot connect to the DHCP server in approximately 1 minute after the IOLAN has fully booted, it will revert to a configuration with all up-links bridged to a 192.168.0.x subnet with the IOLAN assigned to the 192.168.0.1 IP address. At this point, you can use a browser on a PC which is on the 192.168.0.x network to access the IOLAN. You can HTTP/HTTPS to 192.168.0.1 to access Fast Setup mode.


To set a static IP address.

1. Within your PC's Windows operating system or equivalent, select Control Panel, then >Network and Internet >Network Sharing Center >Ethernet >Properties > Internet Protocol Version 4 (TCP/IPv4), and set your PC address to **192.168.0.2/255.255.255.0** then click Ok
2. When the System LED is flashing green, use a web browser and enter <http://192.168.0.1> to access your IOLAN.

Option 2–Console


Connect a terminal to either the RJ45 or USB console port of the IOLAN. Ensure your terminal is set to 115,200 baud, 8 bits, no parity, one stop bit, and no flow control. Press “Enter” on the terminal, and you should now see the Fast Setup prompt.

If using a web browser, the following screen should appear.



On the setup screen, select Get Started or See Options.

1. If you select Get Started, fill in the required fields, apply the changes, then save and exit. The configuration changes will be immediately applied to the IOLAN. You can now access your IOLAN's complete configuration using the credentials you supplied from the WebManager.
2. If you select See Options, the following screen appears.



The third option, “Enable IOLAN configuration via DHCP/BOOTP (ZTP), and reboot,” will cause the IOLAN to reboot. After the software is fully loaded, the up-link ports will be in DHCP client mode and will remain in this mode indefinitely.

Connecting Ethernet Devices

The Ethernet RJ45 ports provide the standard Ethernet interface speeds of 10/100/1000 Mbps. By default, all 10/100/1000 Ethernet ports will automatically set themselves up to match the speed of the attached devices.




Ethernet Ports

Speed	Colour	Side	Description
1000 Mbps	Green	Left solid	Flashes with activity
100 Mbps	Green	Left solid	Flashes with activity
	Yellow	Right solid	Flashes with activity
10 Mbps	Yellow	Right solid	Flashes with activity

Connecting Serial Devices

Connect devices, workstations, servers, or routers using a straight-through or rolled serial cable.



Serial port configured as
Straight


Pin #	Signal	Direction
1	CTS	OUT
2	DSR	OUT
3	RX	IN
4	GND	
5	NOT USED	
6	TX	OUT
7	DTR	IN
8	RTS	IN

Serial port configured as
Rolled

Pin #	Signal	Direction
1	RTS	OUT
2	DTR	OUT
3	TX	OUT
4	GND	
5	DCD	IN
6	RX	IN
7	DSR	IN
8	CTS	IN


RJ45 Console Port Pinout

Pin #	Signal	Direction
1	RTS	OUT
2	DTR	OUT
3	TX	OUT
4	GND	
5	GND	
6	RX	IN
7	DSR	IN
8	CTS	IN



RJ45 to RJ45 Cable Pinout

Pinout	
1	----->1
2	----->2
3	----->3
4	----->4
5	----->5
6	----->6
7	----->7
8	----->8



Connecting USB Devices

The IOLAN USB ports can connect storage devices such as USB flash drives and USB serial devices.